




OBABY

Astrid Changing Unit

Instructions

Version: R1-0-1



**IMPORTANT
KEEP FOR FUTURE REFERENCE**





Safety Warnings

Thank you for choosing to be part of the Obaby family

This changing unit conforms to BS EN 12221:2008+A1:2013 FIRA/FRQG C001 & C004:2016. To ensure that your changing unit is used in accordance with these instructions, please read them fully.

Your child's safety may be affected if you do not follow these instructions.

WARNING: Installation shall be carried out exactly according to the manufacturers instructions otherwise a safety risk can occur if incorrectly installed.

WARNING: Do not leave the child unattended.

WARNING: Assembly should be carried out by a competent adult only.


WARNING: In order to prevent tipping this product must be used with the wall attachment devices provided. Serious or fatal crushing injuries can occur from furniture tipping over.















- The changing unit must be used on a level and stable surface.
- Never move the changing unit with the child on it.
- Be aware of the risks of open fires and other sources of heat, such as electric bar fires, gas fires, etc. in the near vicinity of the changing unit.
- Do not use the changing unit if any part is broken or missing. Use only spare parts approved by the manufacturer.
- We recommend you use a changing mat with maximum dimension of 80cm x 46cm, placing the mat evenly inside the changing unit.
- The changing surface is designed for use from birth until 12 months, max weight 11kg.
- All assembly fittings should be tightened properly and care should be taken that no screws are loose, as a child could trap parts of the body, or clothing (e.g. ribbons, drawstrings, necklaces) this could lead to strangulation.
- Regularly check that all the fittings and components of the changing unit are fully tightened and in working order.
- Wood is a natural material, the colour will darken with age.
- During assembly children should be kept away from the product due to possible risk of injury.

ROUTINE CARE & MAINTENANCE


- ◇ For cleaning, use only a mild detergent and warm water.
- ◇ DO NOT USE BLEACH.
- ◇ DO NOT USE any abrasive substances.
- ◇ Take care when handling or moving furniture, careless handling can damage wooden furniture.

Due to constant updating and improvements, some components may occasionally differ slightly from the images shown in these instructions. We reserve the rights to change the specifications of any products without prior notice. If you need any assistance please contact your Obaby retailer from whom you purchased your product, who will take appropriate action.




P1  3.5x16mm x2	P2  x18	P3  3x16mm x45	P4  x2	P5  x2	P6  x48	P7  x12
P8  x18	P9  x18	P10  x3	P11  x4	P12  x4	P13  x2	P14  x4


Allen Key Included:




Stage 1




Stage 2




Stage 3




Stage 4




Stage 5




Stage 6



Stage 7




Stage 8











Stage 9




Stage 10




Stage 11




Stage 12



Stage 13




Stage 14



We advised for safety reasons that the changing unit is connected to the wall using the wall strap provided. All walls are different composition and the correct fittings should be used to match your walls. Wall fittings are not supplied with this furniture and it is advised to consult a professional before fitting.



Safety Warning



WARNING

IN ORDER TO PREVENT TIPPING THIS PRODUCT MUST BE USED WITH THE WALL ATTACHMENT DEVICES PROVIDED.

Serious or fatal crushing injuries can occur from furniture tipping over. To help prevent tipping:

- Use the wall attachment devices provided
- Never allow children to climb or hang on drawers, doors or shelves
- Place heaviest items in the lower drawers or shelves
- Do not set TVs or other heavy objects on top of this product
- Never open more than one drawer at a time

Attachment devices are provided with your product, however you will need to source suitable fixings for your wall type. If in doubt please consult with a qualified tradesperson.

Always ensure the wall to be drilled is free from hidden electrical wires, water and gas pipes.



OBABY

obaby.co.uk



OfficialObaby



obabyuk



obabyuk



officialobaby






OBABY

Astrid Mini Cot Bed

Instructions

Version: R1-0-1



**IMPORTANT
KEEP FOR FUTURE REFERENCE**



Thank you for choosing to be part of the Obaby family

Our Cot Bed confirms to BS EN 716-1:2017 and BS 8509:2008 + A1:2011. To ensure that your cot bed is used in accordance with these instructions, please read them fully.

Your child's safety may be affected if you do not follow these instructions.

WARNING: A child's safety is your responsibility.

WARNING: Assembly should be carried out by a competent adult only.

WARNING: Do not use more than one mattress in the cot bed.

WARNING: Do not place this child's bed near heat sources, windows and other furniture.

WARNING: Be aware of the risk of open fire and other sources of heat, such as electric bar fires, gas fires, etc in the near vicinity of the cot bed.

WARNING: Do not use this child's bed if any part is broken, torn or missing.

WARNING: Do not leave anything in the cot bed or place the cot bed close to another product, which could provide a foothold or present a danger of suffocation or strangulation, e.g. strings, blinds/curtain cords etc.

- This product is intended for use from birth up to 4 years old.
- Please be aware that the lowest base position is the safest and the base should always be used in that position as soon as the baby is old enough to sit unaided.
- The thickness of the mattress chosen should be such that the internal height (surface of the mattress to the upper edge of the cot frame) is at least 500mm when the base is set in the lowest position and a minimum of 200mm when the cot base is set in the highest position.
- We recommend you use the Obaby Mattress Size 120 x 60 cm for this cot bed. The mattress should be no more than 30mm shorter or narrower than the internal length or width of the cot bed.
- Regularly check that all fittings and components of the cot/bed are fully tightened and in working order.
- To prevent injury from falls, as soon as the child is able to climb out of the cot, it should be changed into the bed mode for use up until 4 years of age.
- The cot bed is designed to be dismantled for storage or transportation.
- Children are likely to play, bounce, jump and climb on beds, therefore the child's bed should not be placed next to other furniture or windows, and should be placed either tight to the wall or have a gap of 300mm between the wall and the side of the bed.
- All assembly fittings should be tightened properly and care should be taken to ensure that no screws are loose, as a child could trap parts of the body, or clothing (e.g. ribbons, draw-strings, necklaces) this could lead to strangulation.
- During assembly children should be kept away from the product due to possible risk of injury.
- Wood is a natural material, the colour will darken with age.
- Use only spare parts approved by the manufacturer.

Routine care & maintenance

For cleaning, use only a mild detergent and warm water.


- ◇ DO NOT USE BLEACH
- ◇ DO NOT USE any abrasive substances.
- ◇ From time to time, check your cot for loose screws, and worn parts. Replace or adjust the parts as needed.















Due to constant updating and improvements, some components may occasionally differ slightly from the images shown in these instructions. We reserve the rights to change the specifications of any products without prior notice. If you need any assistance please contact your Obaby retailer from whom you purchased your product, who will take appropriate action.

*Don't forget to leave a review on our
TrustPilot Page x*



Parts List




P1  40mm x8	P2  x8	P3  x4	P4  x4	P5  x4	P6  x35	P7  x8
P8  x12	P9  x4	P10  x1	P11  x1	P12  x12	P13  x12	P14  x2


You will require a cross head screw driver

obaby.co.uk


Stage 1




Stage 2




Stage 3




Stage 4



Stage 5




Stage 6






Stage 7



Use a cross head screw driver to tighten
P13 fitting




Stage 8




Stage 9




Stage 10



Stage 1




Stage 2






Converting into a Day Bed

Stage 3




Stage 4




Stage 5

Tightened up P8 fittings with cross head screw driver




Stage 6






Converting into a Day Bed


Stage 7




Stage 8



Stage 9



Stage 10





OBABY

obaby.co.uk



OfficialObaby



obabyuk



obabyuk



officialobaby






OBABY

Astrid

Double Wardrobe

Instructions

Version: R1-0-1



IMPORTANT
KEEP FOR FUTURE REFERENCE





Safety Warnings

Thank you for choosing to be part of the Obaby family

This wardrobe conforms to FIRA/FRQG C001 & C004:2016 To ensure that your wardrobe is used in accordance with these instructions, please read them fully.

Your child's safety may be affected if you do not follow these instructions.

WARNING: Installation shall be carried out exactly according to the manufacturers instructions otherwise a safety risk can occur if incorrectly installed.

WARNING: Assembly should be carried out by a competent adult only.

WARNING: In order to prevent tipping this product must be used with the wall attachment devices provided. Serious or fatal crushing injuries can occur from furniture tipping over.

- The wardrobe must be used on a level and stable surface.
- Be aware of the risks of open fires and other sources of heat, such as electric bar fires, gas fires, etc. in the near vicinity of the wardrobe.
- Do not use the wardrobe if any part is broken or missing. Use only spare parts approved by the manufacturer.
- All assembly fittings should be tightened properly and care should be taken that no screws are loose, as a child could trap parts of the body, or clothing (e.g. ribbons, drawstrings, necklaces) this could lead to strangulation.
- Regularly check that all the fittings and components of the wardrobe are fully tightened and in working order.
- Wood is a natural material, the colour will darken with age.
- During assembly children should be kept away from the product due to possible risk of injury.
- This product is suitable for children aged 3-12 + years.


To prevent overloading we recommend the following maximum loads:















- Shelves: 15kg
- Hanging rails: 10kg
- Drawers: 6kg

ROUTINE CARE & MAINTENANCE


- ◇ For cleaning, use only a mild detergent and warm water.
- ◇ DO NOT USE BLEACH.
- ◇ DO NOT USE any abrasive substances.
- ◇ Take care when handling or moving furniture, careless handling can damage wooden furniture.

Due to constant updating and improvements, some components may occasionally differ slightly from the images shown in these instructions. We reserve the rights to change the specifications of any products without prior notice. If you need any assistance please contact your Obaby retailer from whom you purchased your product, who will take appropriate action.




P1  3.5x16m x22	P2  x8	P3  x50	P4  x12	P5  x4	P6  x28	P7  x2
P8  x17	P9  x17	P10  x6	P11  x6	P12  x4	P13  x2	P7  x8



Stage 1




Stage 2




Stage 3




Stage 4





Stage 5




Stage 6






Stage 7



Stage 8




Stage 9





Safety Warning





WARNING!


IN ORDER TO PREVENT TIPPING THIS PRODUCT MUST BE USED WITH THE WALL ATTACHMENT DEVICES PROVIDED.

Serious or fatal crushing injuries can occur from furniture tipping over. To help prevent tipping:

- Use the wall attachment devices provided
- Never allow children to climb or hang on drawers, doors or shelves
- Place heaviest items in the lower drawers or shelves
- Do not set TVs or other heavy objects on top of this product
- Never open more than one drawer at a time

Attachment devices are provided with your product, however you will need to source suitable fixings for your wall type. If in doubt, please consult a qualified tradesperson.

Always ensure the wall to be drilled is free from hidden electrical wires, water and gas pipes.





OBABY

obaby.co.uk



OfficialObaby



obabyuk



obabyuk



officialobaby

